

CAD Compact Helmcke



www.cadcompact.de
Vertrieb@CADcompact.de
T (030) 351 375 35

Lizenzierung im Home-Office

Für die Lizenzierung von CAM350 und BluePrint im Home-Office gibt es mehrere Varianten:

1. **USB Key:** Wenn Sie Ihr DownStream Produkt über einen USB Key lizenzieren, können Sie diesen Key auch an Ihren Rechner zuhause anschließen. Die Installation und Lizenzierung nehmen Sie bitte gemäß der Installations-Anleitung von DownStream Technologies vor.
2. **Netzwerk:** Wenn Ihr Arbeitsplatz über einen Lizenz-Server lizenziert wird, können Sie Ihre Lizenz mittels „license borrowing“ für einen frei wählbaren Zeitraum auf einen Rechner lokal übertragen. Die Lizenz steht dann nicht mehr im Netzwerk zur Verfügung. Sie können die „ausgeliehene“ Lizenz auch früher zurückgeben. Bitte beachten Sie die Installations-Anleitung von DownStream Technologies ab Seite 26 oder die untenstehenden Angaben.

Die überregionale Bereitstellung von Netzwerklizenzen (auf Entfernungen von mehr als 800m) als WAN ist nur über einen abweichenden Lizenzvertrag möglich.

Die jeweils aktuelle Release von CAM350 und BluePrint können Sie im [Downloadbereich](#) unserer Website herunterladen. Hier finden Sie auch die Installations-Anleitung von DownStream Technologies.

Wartungskunden benötigen kein separates Lizenz-File. Wählen Sie „install license from installation medium“ oder folgen Sie den Anweisungen zum license borrowing.

CAD Compact Helmcke



License Borrowing

If you want to use a product license on a client computer while it is disconnected from a license server (for instance a laptop), a license can be borrowed from a license server via a special check out known as license borrowing. With license borrowing, you check out a product license and specify a future date to return the borrowed license. For the specified period, the product license is available exclusively to the remote computer while disconnected from the network.

The license server keeps the borrowed license checked out. The DownStream product uses the local borrowed license during the borrow period. Upon the expiration of the borrow period, the local borrowed license is no longer available on the remote computer and the license server returns the borrowed license to the pool of available licenses.



www.cadcompact.de
Vertrieb@CADcompact.de
T (030) 351 375 35

Running the LicenseBorrow Utility

LicenseBorrow is a DownStream Technologies utility installed in the folder C:\DownStreamTech\LicenseManager.

To Borrow a License:

1. Run LicenseBorrow on the client computer where you want to borrow licenses.
2. Enter the Borrow Expiration Date (dd-mmm-yyyy format).
3. Select **Set Borrow Expiration Date** to set the date of license return.
4. Start the DownStream product to borrow the license features.
5. You can now disconnect your computer from the network and use the borrowed license to run the DownStream product.
6. Select **Don't Borrow Anymore Today** to prevent additional features from being borrowed.

Checking Borrow Status:

1. Run LicenseBorrow on the client computer.
2. Select **List Currently Borrowed Features** to view borrow status.

The client computer does not have to be connected to the network to determine status.

Clearing the Borrow Period:

Once you have borrowed all product licenses required for the current borrow period you can prevent any additional product licenses from being borrowed for the rest of that day.

1. Run LicenseBorrow on the client PC where the license features were borrowed
2. Select **Don't Borrow Anymore Today** to prevent additional borrows.

To Return Borrowed Licenses Early:

1. Stop all DownStream product sessions on the client computer where the license was borrowed.
2. Connect the client computer to the network.
3. Run LicenseBorrow on the client computer.
4. In **DownStream License Manager License File**, enter the DownStream License File name or browse to select the license file.
5. Select **Return Borrowed Licenses Early**. All DownStream Technologies borrowed licenses are returned.